# QUICK START GUIDE

### 1. SIZE



## 2. ON / OFF



• Hold on "(b)" for 3 seconds


## 3.SWITCH MODES



"(b)" to switch modes



## 4. USB CHARGING



- · Connect the device to USB port to charge .
- . Do not use the device while charging.
- · Please connect with power adapter below 5V. . Can not keep in water for a long time.
- . If the product can't be charged when electrified, please wait for 10 mins to

#### 5. PRODUCT CLEANING

- · Clean Please clean product with warm water or antibacterial soap.
- . Wipe Dry the product with clean cloth or towel.
- . Store Keep the product in a cool, dry, clean place.
- · Attention Never clean this product with organic cleaner containing alcohol, gasoline or acetone. Avoid direct sunlight.

#### 6. SAFETY

- Do not use it at temperature over 167 F/75 °C.
- . Stop using it when any discomfort occurs.
- . It is recommended to use it with water-based lubricant.
- . Do not use it if you find the product unsmooth or damaged.
- . Keep out of reach of children.









