



Male Masturbator

User Manual



Specifications


Material	Silicone + ABS
Size	5.39*3.07*1.77in
Net Weight	112.3g
Waterproof	IPX6
Working Frequency	7 frequencies
Working Time	About 100 mins
Noise	<55db



Button Introduction

- Press the "⏻" button for 3s to turn on/off, press again to change the frequencies, 7 frequencies change cyclically.


1.77 in (45 mm)



Turn on/off, change the vibration frequency.

How to Charge

- Magnetic charging design;
- When the charging cable is attached to the 2 magnets on the product, the indicator light up, the button will flash, and the device will start charging.
- It takes 120 minutes to fully charge and can work continuously for 100 minutes. After fully charged, the indicator light stops flashing.



Magnetic charging hole

Cleaning and Maintain

- Clean the device with warm water and soap. And then run it through some hot water to wash any traces of soap.
- Pat it dry with a clean lint-free cloth or a microfiber towel so there is no fluff left on it.
- Put this product in a dry place, keep the storage environment clean and separate from other materials, and away from Children's contact range.
- Don't use alcohol to clean the product, for alcohol would corrode the surface of the product and accelerate its aging process.
- The product waterproof level is IPX6 and not suitable for playing in the water. For its long service life, don't soak it in the water for a long time.