


Renegade MACH I



VIBRATING
ANAL PLUG
WITH REMOTE

For warranty information, latest products, and news visit us at:

nsnovelties.com

PLAY



Renegade Mach I is a vibrating anal plug that can be used with or without the remote control.

* Press and hold the "+" button on the bottom of your Renegade Mach I for 3 seconds to turn it on.


A blue power light will come on indicating that the toy is ready to play.

* Press "+" or "-" button for 1 second to cycle through variable vibration speeds and patterns.

* To turn off the toy, press and hold the "-" button for 3 seconds.

Battery: USB Rechargeable
Vibration: 10 modes
Material: Premium Silicone - Phthalates Free
Waterproof: Waterproof: IPX 6, 5

USING REMOTE



Renegade Mach I comes with a controller that allows you and your partner to change the vibration modes remotely.

Please be sure to turn on/off the power by using the buttons on the bottom of your Mach I.

This remote does not have the capability to turn on or off the power of the toy itself.

CARE

* Turn off your Mach I when not in use.

* Wash after each use with liquid anti-bacterial soap and water.

* Pat dry with soft, cotton towel and allow to air dry completely.


CHARGE



Charge your Mach I by plugging the pin end of the charging cable into the small hole on the device. The other end can go into any USB charger.

It takes about 3 hours to fully charge. Do not charge it overnight.

When it is charging the blue light continues flashing then stops and remains on when fully charged.



nsnovelties

Document Name Renegade Mach I User Guide
Last Modified 1-2-2019
Size 29.7 cm w x 9 cm h
Format Accordion Fold

Cut ———— Fold - - - - -

Copyright © 2018 NS Novelties. All rights reserved. The shape and appearance of this packaging and enclosed product is a trademark and trade dress of NS Novelties.