

**CHROMA**

**SUNRISE  
RECHARGEABLE  
VIBE**

For warranty information, latest  
products, and news visit us at:  
[nsnovelties.com](http://nsnovelties.com)

**CARE**

- \* Turn off device when not in use.
- \* Do not operate the device while charging.
- \* Please follow the charge times indicated in the device specifications.
- \* Wash after each use with liquid anti-bacterial soap and water.
- \* Pat dry with a cotton towel and allow to air dry completely.

**Product**

**Dimensions:** 2.68 x 0.75 x 0.75 (in)

**IPX Rating:** IPX7

**Battery:** Lithium Ion

**Charge Time:** Do not exceed 90 minutes


**Run Time:** 60 minutes

**Modes:** 10



**PLAY**

- \* Press & hold button on device for 2 seconds to power on/off.
- \* Quick press to cycle through vibration modes.



**CHARGE**

- \* The light will blink while the device is charging.
- \* The light will become solid once the device is fully charged.

