

INYA

PASSION RECHARGEABLE RABBIT

For warranty information, latest products, and news visit us at:
nsnovelties.com

CARE


- * Turn off device when not in use.
- * Do not operate the device while charging.
- * Please follow the charge times indicated in the device specifications.
- * Wash after each use with liquid anti-bacterial soap and water.
- * Pat dry with a cotton towel and allow to air dry completely.

Product Dimensions: 8.74 x 1.54 x 2.56 (in)
IPX Rating: IPX5 Low pressure water resistant
Battery: Rechargeable
Charge Time: Do not exceed 150 minutes
Run Time: 60 minutes
Modes: 12



PLAY

- * Press & hold power button on device for 2 seconds to power on and activate thrust function.
- * Quick press power button to cycle through thrust patterns.
- * Quick press vibration button to activate and cycle through vibration speeds/patterns.
- * Press & hold power button for 2 seconds to end functions and power off.



CHARGE

- * The light will blink while the device is charging.
- * The light will become solid once the device is fully charged.

