

GP
GUILTY
PLEASURE

GUILTY PLEASURE

MISSION

At Guilty Pleasure, our mission is to redefine luxury and seduction by creating immersive experiences that elevate the senses. We craft high-end products that embody style, refinement and allure. We empower pleasure-seeking individuals to embrace their desires, step into their sensuality and express their unique identities.

VISION

Our vision at Guilty Pleasure is to shape a world where luxury and refinement inspire every step of the pleasure-seeking journey. We aim to inspire every individual to explore their passions and desires. To pursue their pleasure with confidence and striking elegance.

OUR GOAL

Our goal is to curate an exquisite collection that transcends traditional luxury, providing elevated experiences that enhance personal expression, exploration and intimate connection. We strive to innovate continuously, ensuring that every detail reflects our commitment to sophistication and the high-class art of seduction.

**SOLD AS AN ADULT
NOVELTY ONLY**

PHTHALATE FREE



MORE INFO?



Materials:

Made of Silicone / ABS / Feather /
PVC / Paper / 100% Satin / Polyester
lace / Nylon / PU / Metal / 100% iron

USB charger included.

Made in China
Distributed by Tonga BV
Noordpolderstraat 21
4571 LR AXEL The Netherlands
info@guilty-pleasure.eu

WWW.GUILTY-PLEASURE.EU

EN

HOW TO TURN ON THE BULLET

Your new vibrating bullet comes with a magnetic USB cable. The vibrator is already partially charged but we recommend fully charging your toy before first use. To turn on the bullet press the power button **(1)** for 3 seconds.

HOW TO CHANGE THE VIBRATIONS

To change the vibrations, shortly press the power button **(1)** + to go to the next vibration pattern.

HOW TO TURN OFF THE BULLET

To turn off the vibrator, press the power button **(1)** for 3 seconds.

HOW TO CHARGE YOUR VIBRATOR

Your bullet can be easily charged with the included magnetic USB cable. Gently click the magnetic cable on the magnetic contact points on the device **(2)**. A flashing LED-light indicates the activation. It takes 90 minutes to fully charge. Once fully charged the playtime is 90 minutes at the lowest speed and 50 minutes at the highest speed.





710180 - BURNING BLISS GIFTSET

HOW TO CLEAN THE BULLET

We strongly recommend always cleaning your toy with a non-alcohol based toy cleaner after every use. Toy cleaners are dermatologically gentle on the skin and ensure that bacteria are completely removed. This way you prevent infections and take care of your intimate hygiene.

In addition, it extends the life of your toy! Spray your toy with the toy cleaner and wipe it dry with a clean lint-free cloth. When your toy is completely dry, it is best to store it in a storage bag (included).

Caution

This product is not intended for therapeutic purposes. It should not be used on swollen or inflamed areas of the skin. Prolonged and frequent use is not advised or recommended.

BDSM is all about surrender and trust. Always respect your partner's boundaries.



HOW TO TURN ON THE SATISFYER

Press the power button **(1)** for 3 seconds to turn on the vibrator.

HOW TO CHANGE THE VIBRATIONS

Make sure the vibrator is turned on. Shortly press the power button **(1)** + to go to the next vibration pattern. To go back to the former vibration pattern, shortly press the wave button **(2)**.

HOW TO TURN OFF THE SATISFYER


To turn off the vibrator, press the power button **(1)** for 3 seconds.

HOW TO CHARGE

This vibrator comes with a magnetic USB cable. Gently click the magnetic USB-connector on the magnetic contact points on the device **(3)**. A flashing LED light indicates the activation. It takes 120 minutes to fully charge. Once fully charged the LED light stops flashing and play time is 60 minutes at lowest speed and 45 minutes at highest speed.

HOW TO CLEAN THE BULLET AND THE SATISFYER

We strongly recommend always cleaning your toy with a non-alcohol based toy cleaner after every use. Toy cleaners are dermatologically gentle on the skin and ensure that bacteria are completely removed. This way you prevent infections and take care of your intimate hygiene.



In addition, it extends the life of your toy! Spray your toy with the toy cleaner and wipe it dry with a clean lint-free cloth. When your toy is completely dry, it is best to store it in a storage bag (included).

Caution

This product is not intended for therapeutic purposes. It should not be used on swollen or inflamed areas of the skin. Prolonged and frequent use is not advised or recommended.

BDSM is all about surrender and trust. Always respect your partner's boundaries.



710180 - BURNING BLISS GIFTSET

7-piece Gift Set:

- Vibrating Bullet
- 52-piece Card game 'Between Us'
- Dice Set
- Tickler
- Lace Mask
- Bondage Ribbon (2X)
- Satisfyer





Material:

- Silicone + ABS
- Paper
- 100 Iron
- Feather + PVC
- Polyester lace
- Nylon
- Silicone + ABS

GP
GUILTY
PLEASURE

**710180 - BURNING BLISS
GIFTSET**





**710180 - BURNING BLISS
GIFTSET**



GUILTY PLEASURE