



Product Specifications:

Category: Vibrator
User: Women
Material: Silicone and ABS
Finish: Painting
Size: H: 30.6cm W: 5.5cm D:
5.5cm
Battery: 18560 | lithium battery
2200mAh
Voltage: DC3.7V
Number of Vibrations: 10
User time: >50min
Sound Level: <dB



CHARGING INSTRUCTIONS

This vibrator arrives partially charged, so it is recommended to fully charge before use.

Connect the USB plug into the USB port of your computer or other output and the other end of the magnetic output attached to toy's magnetic input.

Initial charge will take less than an hour, and subsequent charges will take less than 4 hours to complete from completely empty.

The indicator light will flash while device is charging, and remain solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 100 minutes of play time at the lowest level, and about 50 minutes at the highest level.

Toy vibration slows before stopping completely when charge is fully depleted.

This toy comes with a rechargeable 18560 lithium battery (2200mAh) and operates at a voltage level of DC3.7V.

INSTRUCTIONS FOR USE

This toy has a simple two-button control. One power button, and one function toggle button.

To turn toy on, press the Power button for at least 3 seconds. The toy will start at the 3rd function, which is the strongest constant vibration function. Once toy is turned on, use the function toggle button to cycle up or down through eight different vibration speeds and patterns.

To turn toy off, press button for at least 3 seconds.