

Product Specifications:

Material: Silicone Battery: Li-ion battery, 3.7V/600mAh Voltage: 5V Number of Vibrations: 9 vibration (2 motors) User time: 35-50 minutes Sound Level: <55dbs

CHARGING INSTRUCTIONS
This toy arrives with a partial charge. It is recommended to charge fully before first. To charge, connect the USB plug into a power source and the magnetic DC charger onto the pins at the back of the toy's

Initial and subsequent charges will take about 90 minutes to

complete. The indicator light will flash while device is charging and stay constant when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods or time.
Charge lasts for about 35 minutes of play time
at the highest level of vibration, and about 50
minutes at the lowest level.
This toy operates at a sound level of less than
55db with a 600mAh rechargeable lithium
battery at 3.7V / 5V. INSTRUCTIONS FOR USE This toy has a convenient 1-button control at the base of its handle that operates both motors together. To turn toy on, press the button for 3 seconds. The LED light will illuminate and both motors will begin vibrating at their lowest frequency. Press the button again, a single time for each new speed or function for a total of 9. To turn toy off, press button for 3 seconds. Both motors will stop and light will turn off. ATTACH USB CHARGER • TO PRONGS **USB RECHARGEABLE**