

Product Specifications:

Material: Silicone + **ABS Plastic**

Battery: Rechargeable lithium battery, 502030 250mAh

Voltage: 3.7V

Number of Functions: 7 User time: 60 minutes Sound Level: 55dbA

CHARGING INSTRUCTIONS

CHARGING INSTRUCTIONS
This massager arrives with a partial charge of about 30%-50%, so it is recommended to fully charge before use.
Connect the USB plug into the USB port of your computer or other output and the other end of the charger to the toy's magnetic pin input. The magnetic pins are located below the control panel at the base of the toy's handle.

Initial charge will take about 1 hour, and subsequent charges will take about 2 hours to complete.

complete.

complete.
The indicator light will flash while device is charging and remain solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.
Charge lasts for about 90 minutes of play time on

the lowest level function, and about 60 minutes on

the highest level. Tapping intensity decreases as the battery charge

This toy operates at a sound level of less than 55db with a rechargeable 250mAh lithium battery at 3.7V.

INSTRUCTIONS FOR USE

This toy has a convenient 2-button control at its

To turn motor on, press the top Power Button for at least 2 seconds. The indicator light will turn on and tapping function will begin at its lowest frequency. Once the toy is on, use the bottom Function Button to

ATTACH USB CHARGER TO PRONGS cycle through 7 tapping speeds and functions. The indicator light will flash once for every new speed or function. To turn motor off, press the top Power Button for at least 2 seconds.

USB RECHARGEABLE

