

Product Specifications:

Material: Silicone & ABS Battery: 900 mAh Voltage: 3.7V Number of Vibrations: 3 vibrating, 3 movement User time: 40 - 60 Minutes Sound Level: ≤60db

CHARGING INSTRUCTIONS

It is recommended to charge before first use. To charge, connect the USB cable to a power source and place the DC end onto the magnetic charging pins at the back of the toy's handle. The light flashes when the toy is charging and turns solid when complete. Charges will take about 2.5

solid when complete. Charges will take about 2.5 hours to complete.
Battery charge lasts for about 1 hour on the lowest frequency, and 40 minutes on the highest frequency. This toy operates at a sound level of less than 60db with a 900mAh lithium battery at 3.7V.

INSTRUCTIONS FOR USE

1. The 3-button control panel is located at the front of the toy's handle. Each button operates its own motor and

function.

2. Press the bottom button for 2 seconds to engage vibration in the stimulator. The light will turn on and vibration will begin at the slowest speed. Press again to cycle through 3 speeds. Press for 2 seconds to turn this motor off.

3. Press the middle button for 2 seconds to engage ting may present in the main.

to engage ring movement in the main shaft. The light will turn on and ring movement will begin at its highest speed. Press again to cycle through 3 speeds. Press for 2 seconds to turn this motor off.

4. Press the top button for 2 seconds to engage vibration in the main shaft. The light will turn on and vibration will begin at the slowest speed. Press again to cycle through 3 speeds. Press for 2 seconds to turn this motor off.



USB RECHARGEABLE