

Product Specifications:

Material: Silicone & ABS Battery: 1000mAh Voltage: 5V

Number of Vibrations: 10 vibrating, 10 thrusting/twirling User time: 60 - 180 Minutes Sound Level: <50dB

CHARGING INSTRUCTIONS

INSERT Charger Here

USB RECHARGEABLE

It is recommended to charge before first use. To charge, connect the USB cable to a power source and insert the DC end into the charging port at the back of the toy's handle. The light flashes when the toy is charging and turns solid when complete. Initial charge will take about an hour and subsequent

charges about 3 hours to complete.
Battery charge lasts for about 3 hours using one function and about 1.3 hours using all three functions. This toy operates at a sound level of less than 50db with an 1000mAh lithium battery at 5V.

INSTRUCTIONS FOR USE

1. This toy has a 3-button control panel located at the front of the toy's handle. 2. Press the middle power button for 3 seconds to turn on the toy. The button will light up and all 3 motors will begin in standby. Press the power button more quickly to cycle through 10 different speeds of thrusting and twirling in the main shaft. 3. Once the toy is in standby, press the top button to engage the vibration motor in the main shaft. Cycle through 10 vibration speeds and patterns. Press this button for at least 2 seconds to return the toy to standby. 4. Once the toy is in standby, press the bottom button to engage the vibration motor in the clitoral shaft. Cycle through 10 vibration speeds and patterns. Press this button for at least 2 seconds to return the toy to standby. 5. To turn the toy off, press the middle

power button for at least 3 seconds. Lights will turn off and all motors will cease.