

Product Specifications:

Material: Silicone & ABS Battery: Lithium battery

Voltage: 3.7V

Number of Vibrations: 10 User time: 50 - 70 Minutes Sound Level: ≤50dB

CHARGING INSTRUCTIONS

This toy arrives with a partial charge of about 70%. Initial charge will complete in about 90 minutes; subsequent charges will complete in about 2 hours. Connect the USB

cable to a power source at one end and place the DC end onto the magnetic charging pins at the base of the toy. An indicator light flashes while the toy is charging and goes solid when it's done. Battery charge lasts for about 70 minutes on the lowest frequency, and about 50 minutes on the

highest frequency of play. This toy operates at a sound level of less than

50db at 3.7V.

INSTRUCTIONS FOR USE

- 1. The 1-button control panel is located at the base of the toy.
- 2. Press the button for 2 seconds to turn the toy on. The light will turn on and the motor will begin at its lowest speed.
- 3. Press the button again more quickly to cycle through 3 speeds and 7 patterns.

ATTACH USB CHARGER TO PRONGS

4. Press the button for 2 seconds to turn the toy off. The light will turn off and the motor will stop.

USB RECHARGEABLE