Ozerotolerancetoys.com





Product Specifications:

Material: Silicone & ABS
Battery: 102540 Lithium Polymer
Battery 1200mAh
Voltage: 3.7V
Number of Vibrations: 7 vibrating,
5 thrusting & rotating
User time: 45 - 50 Minutes
Sound Level: <60db

CHARGING INSTRUCTIONS

INSERT

HERE

CHARGER

this recommended to charge before first use. To charge, connect the USB plug into a power source and the DC charger into the charging port at the bottom of the toy's handle. The indicator light will flash while device is

charging and stay constant when toy is fully charged. Initial charge will take 150 minutes, subsequent charges 120 minutes. Charge lasts for 45 minutes of play time at the highest speeds and 50 minutes at the lowest speeds. This toy operates at a sound level of less than 60db with a rechargeable 1200mAh lithium battery at a voltage of 3.7V.



1. The control panel is located at the front of the toy's handle. Press the power button for 3 seconds

to turn the toy on. The button will light up and toy will begin in standby mode.

2. Press the power button again more quickly to engage the thrusting & spinning motor and cycle through 5 speeds of thrusting and spinning. Blue arrows light up one at a time when cycling through the functions. Double click the power button to put thrusting and spinning functions into standby.

3. Once the toy is powered on and in standby, press the vibration button to engage vibration in the inner sleeve. Click again to cycle through 7 speeds and patterns.

4. To turn the toy off, press the power button for 2 seconds. Lights will turn off and all vibration will cease.

USB RECHARGEABLE