




VIBRATOR CARE INSTRUCTIONS

1. Take care when using the vibrator for the first time. Vibration can be intense.
2. Clean your vibrator after every use.
3. Take care when cleaning your vibrator. Remember it is an electrical item.
4. Keep your vibrator clean and dry. Store in a non-damp environment.
5. Always store your vibrator separately. Different materials have different chemical configurations and may react with each other.
6. Always allow your vibrator to cool down before storing in a safe place. Vibrators are electrical and motors grow warm with use.
7. Excessive usage of the vibrator will wear out the motor and may cause the motor to overheat. If you feel your vibrator is getting unduly hot, switch off and allow it to cool down, before continuing use.
8. Take care when using oils and lubricants so that they do not enter the battery compartment as they can react with the batteries.



CHARGING INSTRUCTIONS

This vibrator arrives with a partial charge, so it is recommended to charge it fully before use. Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input.

Initial charge will take 2-3 hours, and subsequent charges will also take about 2-3 hours to complete.

The indicator light(s) will flash while device is charging, and remain solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 1 hour of play time on the lowest vibration level, and about 25 minutes on the highest level.

This toy comes with a rechargeable li-ion battery 13450, operates at DC 3.7V and a sound level of 45db.

INSTRUCTIONS FOR USE

This toy has an easy to use 2-button control. Press the Power button for at least 2 seconds to turn the toy on.

After the toy is turned on, use the Function button to cycle through 9 different vibration patterns and speeds.

Press the Power button for at least 2 seconds to turn the toy off.

USB RECHARGEABLE

